

Declaration of Conformity

Model Number: **XID 83xx Printer** (x=A-Z,0-9 or blank)

Product Name: **Retransfer Card Printer**

We herewith declare that the above mentioned product complies with the following council directives and harmonized standards.

Council Directives: 1999/5/EC relating to radio equipment and telecommunications terminal equipment

2004/108/EC relating to electromagnetic compatibility


2006/95/EC relating to electrical equipment designed for use within certain voltage limits.

Harmonized Standards: EN55022:2006 Class A+AL
EN55024:1998 + A1:2001 + A2:2003
EN61000-3-2:2006
EN61000-3-3:1995 +A1:2001 +A2:2005
EN60950-1:2006
EN50371:2002
EN300330-2:V1.1.1
EN301489-03:V1.41

Importer and Distributor: Digital Identification Solutions AG
Teckstrasse 52
73734 Esslingen Germany

Place/Date of issue: Esslingen, September 2009

Signature:


.....
Manfred Arnold
Senior VP Hardware R & D and Support

Digital Identification Solutions AG
Teckstrasse 52, 73734 Esslingen Germany
Phone : +49 711 341 689 - 0
Fax : +49 711 341 689 - 550

EDISecure® XID 8300 Retransfer Card Printer

Thank you for purchasing this product.

Please read through the "Electronic Manual" in the CD-ROM carefully in advance to ensure proper use of this product. Also, to make sure that the product is used safely, please read through the "READ ME FIRST" booklet. Please store the manuals properly after reading so that they can be referred to whenever necessary.

Place this "Getting started guide" near the printer and use it as and when needed. Click  in the "Electronic Manual" of the CD-ROM to print out the necessary PDF files. Store the printed PDF files between the pages of this "Getting started guide".



Accessories

- CD-ROM1
- Instruction Manual.....1
- Read Me First: LST10131
- Power Cord (2 m).....3
- Cleaning Card1
- Card Stacker1
- USB 2.0 Cable: QAM1196 (2m)1
- Gloves1

Products sold separately: Ink Ribbon/Retransfer Film

To purchase these items, consult our authorized dealers.

- Ink Ribbon (YMCK), 1,000 frames/roll (Model: DIC10216)
- Ink Ribbon (YMCKK), 750 frames/roll (Model: DIC10217)
- Ink Ribbon (YMCK-PO), 750 frames/roll (Model: DIC10218)
- Ink Ribbon (YMCK-UV), 750 frames/roll (Model: DIC10313)
- ART Retransfer Film, 1,000 frames/roll (Model: DIC10319)
- Cleaning Kit (Model: DIK10044)
Set incl. 10 print head cleaning swabs, 10 cleaning tissues for rollers and 10 special cleaning cards
- Magnetic Stripe Encoder Head Cleaning Cards (Model: DIC10311)
Box of 10 cards

CD-ROM Content

- Electronic Manual
- Software Development Technical Information

Content of Electronic Manual

- Setup..... Installation, connection, setting, etc.
- Getting Started..... Precautions, disclaimer, etc.
- OperationProcedures for printing cards
- Replacement.....Procedures for replacing consumable items
- Maintenance.....Cleaning procedures
- Troubleshooting..... Actions to take when troubles occur

Specifications

- Operating environment conditions .. Temperature: 15 °C to 30 °C
Humidity: 35 % to 70 %
- Storage environment conditions..... Temperature: -15 °C to 55 °C
Humidity: 20 % to 80 %
- Power supply..... AC 100 V - 120 V/AC 220 V - 240 V
50 Hz/60 Hz (allowance ±10 %)
- Power consumption..... 310 W (max.)
- Current consumption.....3.5 A (100 V system)/
1.6 A (200 V system)
- Mass..... Standard approx. 12.5 kg
(excluding optional built-in items)
- Dimensions 343 mm x 360 mm x 322 mm (W x H x D)
* The specifications and appearance of this product may be modified for improvement without prior notice.

Function & Option Checklist


Use the checklist below to identify the functions and options of the printer in use. Tick accordingly.

Model name:


Function	
Single-sided Printing	Double-sided Printing

Option			
Bend Remedy	Magnetic Encoder	Contact IC Encoder	Non-contact IC Encoder

Name of Parts




Replacing the Ink Ribbon/Retransfer Film



Precautions

- If the security lock function is turned on, turn off the function from the computer to unlock the printer. After closing the door, turn on the function again from the computer.
- When replacing the ink ribbon/retransfer film, hold the cassette with both hands.
- When installing a used ink ribbon, align the yellow side of the unused ribbon with the arrow indicated on the label of the cassette.
- When installing a used retransfer film, align the unused side of the film with the arrow indicated on the label of the cassette.
- Stand the cassette on a flat surface as illustrated in the diagram.
- Remove any slack in the ink ribbon/retransfer film. Failure to do so may cause jams or result in uneven colors due to wrinkles on the surface.
- Do not touch the inked/retransfer surface (the side that faces outward when installed) with your hand. Put on the supplied gloves when handling the ink ribbon/retransfer film.
- Do not perform work on the printer door. Do not place heavy objects or apply load on the printer.
- When installing a new retransfer film, make sure that at least three black lines are wound onto the winding shaft.

Printing Cards




- Turn on the power.
- Check to ensure that cards are inserted into the card hopper.
- Open the print settings screen, and select this printer in [Printers].
- After ensuring that a [Ready] message appears on the LCD control panel of the printer, start printing.

Precautions

- If you see a [Initializing...] or [Preheating...] message on the LCD control panel of the printer, this means the printer is not ready yet. Printing cannot be performed until the printer is ready.
- Printing the card on the side with the magnetic stripe may cause printing errors or damage to the card's functions. If you want to do so, consult our authorized dealers in advance.

Loading Cards




- Set the card hopper knob to [open].
- Lift to remove the card hopper cover.
- Align the orientation of the cards, and set them in the printer.
- Install the card hopper cover.

Precautions

- If the security function is turned on, the card hopper will be locked. Turn off the security from the computer. After loading the card, turn on the security again from the computer.
- When a [Loading] message appears on the LCD control panel, do not open the card hopper.
- Direct contact of your hand with the printing surface of the card may result in printing errors.
- When inserting new cards, they may be adhered to each other due to static, thus causing card jams. Separate the cards one by one before setting them in the printer.

Maintenance of Cleaning Rollers



- Open the printer door.
- Pull out the cleaning unit.
- Wash the cleaning rollers with water.
 - Wash the roller unit with water, and remove any dirt from the surface of the cleaning rollers.
- Allow the cleaning rollers to air dry.
- Install the cleaning unit, and close the printer door.

Precautions

- If the security lock function is turned on, turn off the function from the computer to unlock the printer. After closing the door, turn on the function again from the computer.
- After washing, allow the cleaning rollers to dry completely before installing them to the printer.
- Do not use alcohol or detergents.
- Printing errors may occur if the dust removal capability of the cleaning rollers deteriorate. Make sure to clean the rollers at the end of the work.
- Replace the cleaning unit with a new one after using it for about one year. For details on replacement of the cleaning unit, please consult our authorized dealers.